

Beats Audio™ Installer ★ root Uninstallation guide


rev. 1 - 2012/10/31

1: Your device is not bricked and you have access to Android.

- a) Make sure you still have root.
- b) Now download an Root explorer like Root Browser Lite from Google Play.
- c) In Root Browser Lite confirm the download of utilities (when prompted).
- d) Using Root Browser Lite delete the files listed below. (e.g. /system/bin/beatsbass).
ATTENTION: You are deleting system files so double-check if you delete the correct file, otherwise you might damage your Android installation.

2: Your device is bricked and you don't have access to Android.

- a) Make sure you get access to your Recovery or Bootloader.
- b) Install Android Developer Tools on your PC or Mac.
- c) Connect your phone to your PC or Mac.
- d) Open cmd or Terminal, move to the path where adb is stored and type in
adb shell
- e) ENTER, then
su
- f) ENTER, then
busybox mount -o rw,remount /system
- g) ENTER, then
chmod 777 /system
- h) ENTER, then do this for every Filename from the list below (where FILENAME is e.g. //
system/bin/beatsbass)
rm -r FILENAME
- i) ENTER for every line, then
su -c reboot
- j) ENTER



```
Pauls-MacBook-Pro:~ paulgavrikov$ adb shell
root@android:/ # su
root@android:/ # busybox mount -o rw,remount /system
root@android:/ # chmod 777 /system
root@android:/ # rm -r /system/bin/beatsbass
root@android:/ # reboot
```

FILES INSERTED BY BEATS (DELETE THEM)

/system/bin/basimage_gec.bin
/system/bin/basimage_gec_x.bin
/system/bin/basimage_ibeats.bin
/system/bin/basimage_ibeats_solo.bin
/system/bin/basimage_ibeats_solo_x.bin
/system/bin/basimage_ibeats_x.bin
/system/bin/beatsbass

/system/bin/beatsnormal
/system/bin/dynimage_gec.bin
/system/bin/dynimage_gec_x.bin
/system/bin/dynimage_ibeats.bin
/system/bin/dynimage_ibeats_solo.bin
/system/bin/dynimage_ibeats_solo_x.bin
/system/bin/dynimage_ibeats_x.bin
/system/bin/mm-audio-acdb-test
/system/bin/mm-venc-omx-test720p
/system/bin/mm-video-encdrv-test
/system/bin/peqimage_gec.bin
/system/bin/peqimage_gec_x.bin
/system/bin/peqimage_ibeats.bin
/system/bin/peqimage_ibeats_solo.bin
/system/bin/peqimage_ibeats_solo_x.bin
/system/bin/peqimage_ibeats_x.bin
/system/bin/snd
/system/bin/snd8k
/system/bin/sound
/system/bin/sound8x60
/system/bin/spkamp
/system/etc/audio
/system/etc/init.d/981padecode
/system/etc/init.d/98xloud
/system/etc/permissions/com.srs.fusion.fx
/system/etc/soundimage
/system/etc/AdieHWCodec
/system/etc/AdieHWCodec_BEATS_HW
/system/etc/AIC3254_REG
/system/etc/AIC3254_REG_DualMic
/system/etc/AIC3254_REG_XD
/system/etc/audio_effects.conf
/system/etc/AudioBTID

Beats Audio™ Installer ★ root Uninstallation guide

rev. 1 - 2012/10/31

```
/system/etc/AudioFilter
/system/etc/AudioFilterPlatform
/system/etc/AudioFilterProduct
/system/etc/AudioPreProcess
/system/etc/AutoVolumeControl
/system/etc/basimage_gec.bin
/system/etc/basimage_gec_x.bin
/system/etc/basimage_ibeats.bin
/system/etc/basimage_ibeats_solo.bin
/system/etc/basimage_ibeats_solo_x.bin
/system/etc/basimage_ibeats_x.bin
/system/etc/CodecDSPID
/system/etc/CodecDSPID_NEL
/system/etc/CodecDSPID_WB
/system/etc/dynimage_gec.bin
/system/etc/dynimage_gec_x.bin
/system/etc/dynimage_ibeats.bin
/system/etc/dynimage_ibeats_solo.bin
/system/etc/dynimage_ibeats_solo_x.bin
/system/etc/dynimage_ibeats_x.bin
/system/etc/HP_Audio
/system/etc/peqimage_gec.bin
/system/etc/peqimage_gec_x.bin
/system/etc/peqimage_ibeats.bin
/system/etc/peqimage_ibeats_solo.bin
/system/etc/peqimage_ibeats_solo_x.bin
/system/etc/peqimage_ibeats_x.bin
/system/etc/TPA2051_CFG
/system/etc/TPA2051_CFG_BEATS_HW
/system/etc/TPA2051_CFG_XC
/system/lib/soundfx/libbeatsbass.so
/system/lib/soundfx/librsfx.so
/system/lib/soundfx/libxloudwrapper.so
/system/lib/libhoundaudio.so
/system/lib/libSR_AudioIn.so
/system/lib/librsfx.so
/system/lib/TPA2051_CFG_XC
/system/lib/TPA2051_CFG_XC
/system/lib/TPA2051_CFG_XC
```